

WILLIAMS PARTY RENTALS

www.willparty.com

845 Park Avenue, San Jose, CA 95126 • 408.297.1078 • fax 408.297.9507

CHAMPAGNE FOUNTAIN

Operating Procedures

- Pour champagne or clear punch (no pulp) into bowl of fountain (at least 1/2 full).
- Use 3 to 2 prong adapter or grounded outlet.
- Plug in fountain when ready to serve.
- Float dry ice in beverage bowl to chill.
- Rinse with clear water after use.

Safeguards

- Do not immerse cord, plug or electrical base in water or other liquids.
- Never leave children unattended when near unit.
- Unplug when not in use.
- Secure cord from heat or possible hazards.