



PLEXI GLASS BAR

OPERATING INSTRUCTIONS:

- ◆ Plug in bar to outlet.

USING THE CONTROL PANEL:

- ◆ Press the **[MODE]** button repeatedly until the display reads **[ACT]**.
- ◆ Press **[ENTER]**
- ◆ Press the **[UP/ DOWN]** buttons to select the desired color. See table below for options.

WARNING:

- ◆ Always make sure that you are connecting to the proper voltage and that the line voltage you are connecting to is not higher than that stated on decal or rear panel of the fixture.
- ◆ To prevent risk of fire or shock, do not expose fixture to rain or moisture. Make sure there are no flammable materials close to the unit while operating.
- ◆ Make sure power cord is never crimped or damaged.
- ◆ Never disconnect power cord by pulling or tugging on the cord.
- ◆ Avoid direct eye exposure to lamp while it is on.

SPECS:

- ◆ **Electrical Power Required:** Between 100 - 240 volts.
- ◆ **Dimensions:** 8'L x 2.5'W x 3.5'H
- ◆ **Weight:** ~ 100 lbs.

CODE	000	001	002	003	004	005	006	007
COLOR	Blackout	Red	Green	Blue	Yellow	Purple	Cyan	White

