



SNO-CONE MACHINE

PREPARATION:

- ◆ Set the cabinet on the drip tray. Make sure to put the drain hole over an area that is okay to get wet or into a bucket. Melted ice, and condensation go into the drip tray.

OPERATING INSTRUCTIONS:

- ◆ Plug in machine. Turn **[ON]** light switch (located on front of cabinet). Light will come **[ON]** in cabinet.
- ◆ Push and hold the motor button.
- ◆ Wait for the motor to come to full speed.
- ◆ Fill the gooseneck to within an inch of the top with ice cubes or block ice. The larger the pieces, the better the snow.
- ◆ Push the pusher handle down against the ice in the gooseneck. Apply firm and even pressure to make the best snow.
- ◆ Too much pressure will result in snow that is coarse; too little pressure will make the snow mushy.
- ◆ Repeat steps until you have enough shaved ice.

WARNING:

- ◆ The Snow Cone Machine can take ice cubes or block ice only if you break the block into pieces approximately 3 to 4 inches in size. The ice will not enter the shaving chute if it's too large. The design of the shaving chute automatically draws the ice against the blades. There is no need for manual effort. As a safety feature, the motor will only run while the motor button is pressed.

CLEAN UP:

- ◆ Wipe all water and any syrup off of the cabinet inside and out.

SPECS:

- ◆ **Electrical Power Required:** 110 volts, 6.8 amps.
- ◆ **Dimensions:** 14"**D** x 24"**W** x 28"**H**
- ◆ **Weight:** ~ 38 lbs.

